



Synchronized Clocks for Mental Health Facilities and Psychiatric Hospitals - V1.3

Synchronized Clocks provide accurate and uniform time throughout the facility allowing patients, employees, and visitors to utilize the same time source.

Maximizing efficiency and productivity, Synchronized Clocks are used in many types of facilities in order to eliminate any confusion caused by different or inaccurate time sources.

In Mental & Healthcare facilities, a Synchronized Clock System is very important as it serves as the facility's official time source in order to accurately document medical event times, dispense medication, time medical procedures, and keep patients conscious of time. A Synchronized Clock System will automatically adjust for Daylight Saving Time (DST); therefore, there is no need to send maintenance personnel twice a year to adjust all the clocks in the facility.

In mental health facilities and psychiatric hospitals, additional considerations are taken to minimize the risk to patients who may attempt to harm themselves or others using objects in the facility. As such, special attention is given to items placed in high-risk areas.

Sapling offers synchronized clocks with an anti-ligature design for mental health facilities and psychiatric hospitals with high-risk areas.



The Sapling Company, Inc.

670 Louis Drive, Warminster, Pennsylvania 18974 U.S.A

Phone: +1.215.322.6063 Fax: +1.215.322.8498 Web: www.sapling-inc.com



Synchronized Clocks for Mental Health Facilities and Psychiatric Hospitals

There are two options of anti-ligature solutions available:

1. **Flush Mounted Digital Clocks:** The body of the clock is installed inside of the wall; therefore, only the display is visible on the surface of the wall. The flush mounted clock is offered with an anti-ligature front frame secured to not only the clock housing (gang box) but also to the wall.

The flush mounted digital clocks are offered with either 4-digits (00:00) or 6-digits (00:00:00) with a standard Red display or optional White, Amber or Green display.

2. **Flush Mounted Housing and front frame for 12" Analog Square Clocks:** The body of the clock is installed inside of the wall; therefore, only the clock dial is visible on the surface of the wall. The flush mounted clock is offered with an anti-ligature front frame secured to not only the clock housing (gang box) but also to the wall.

The digital clocks are hard-wired; however, the analog clocks may be either hard-wired or battery-operated synchronized clocks.

Our Team will be happy to consult and to provide additional information about our Synchronized Clocks and systems.

Please feel free to contact us at: info@sapling-inc.com or call us at: 215-322-6063

Division 27 | Communications Clocks



Installation Notes
It is recommended to specify recessed wall clocks with polycarbonate lenses.



Sapling Synchronized Clock Systems
www.sapling-inc.com



Flush Mount Housing Kit for an Analog 12" Square Clock (V1.0) (A-FLUSH-MNT-12S-KIT-1)

Frame for analog clocks within a synchronization system with built-in web interface, data received from preprogrammed third party NTP servers for reliability and redundancy, built-in self-diagnostics and email alerts for various functions, and ability for users to view, monitor, and send various commands to all IP clocks in the system. Provides automatic daylight saving time changes, and 12 or 24 hour display.

Compatible with SAL, SAP, SAW, and SAM Series clocks, providing different synchronization technologies.



Sapling Synchronized Clock Systems
www.sapling-inc.com



Digital Flush Mounted Polycarbonate Frame (V1.0) (D-XXX-FIL-XXX-F-KIT-1)

Frame for digital clocks within a synchronization system with built-in web interface, data received from preprogrammed third party NTP servers for reliability and redundancy, built-in self-diagnostics and email alerts for various functions, and ability for users to view, monitor, and send various commands to all IP clocks in the system.

Compatible with SBP and SBD Series clocks, providing different synchronization technologies.

*Published in OMH
Patient Safety Standards 27th
Edition - January 31st, 2022

The Sapling Company, Inc.

670 Louis Drive, Warminster, Pennsylvania 18974 U.S.A

Phone: +1.215.322.6063 Fax: +1.215.322.8498 Web: www.sapling-inc.com